



DRILL JACKSCREW HOLES IN WOOD, AT LEAST 1/2", BEFORE SAWING VEE'S.

